



EQUIPMENT UPDATE

Effective Date: February 24, 2006

Log Number: EU-2-373

Part: DOOR HANDLE SUPPORT

Models Affected: MODELS AH, B, CMA180, CMA180T, CWS, EVA, CB, E



PHOTO A



PHOTO B

Field reports indicate the door safety switch (photo A) has the potential of coming loose and causing machine malfunctions. A CMA service representative has suggested the following change be made - Install screw with nut behind the door safety switch. (See the screw with nut placed along side of door safety switch - photo B). The change has been made by pivoting the lower end of the switch towards the back of the machine, drilling a hole for a screw and nut and securing in place. The head of the screw prevents the switch from coming out of alignment or moving. Future machines will have this change. Suggestions from CMA Service Representatives are always welcomed and appreciated.