


SERVICE BULLETIN

Date: MAY 20, 2009

Log Number: 116

Models Affected: ALL LOW TEMP MACHINES

Subject: CAM TIMER



Caution: To avoid chlorine entering the machine too early (meaning before water has begun filling the machine), resulting in possible chlorine damage to your dishwasher, **RESET** your timer as follows:

At the end of the **DRAIN CYCLE**, **DELAY** the **SANI-INJECTION "START-POINT"** 3-4 seconds; this will eliminate the chance of chlorine entering a "dry" machine and causing damage to the stainless.



12700 KNOTT AVENUE
GARDEN GROVE, CALIF. 92841
800-854-6417 • 714-898-8781
FAX 714-895-2141
www.cmadishmachines.com